



Pneumatic Division
Richland, Michigan 49083

FRL-SIF-105

**08 Series to General Line
Cross Reference**

**ISSUED: November, 2005
Supersedes: None**

08 SERIES TO GENERAL LINE CROSS REFERENCE

| 08 Series Part Number | General Line Replacement No. | Notes |
|----------------------------------|---|--------------|
| Filters | | |
| 08F43AC | F602-06EJ | |
| 08F43AC1 | F602G06EJ | |
| 08F43AC9 | F602G06EJ | |
| 08F44AC | F602-06WJ | |
| 08F44AC1 | F602G06WJ | |
| 08F44AC9 | F602G06WJ | |
| 08F47AC | F602-06EJR | |
| 08F48AC | F602-06WJR | |
| 08F48AC1 | F602G06WJR | |
| 08F4GAC | F602-06EJ | |
| 08F4HAC | F602-06WJ | |
| 08F53AC | F602-08EJ | |
| 08F53AC1 | F602G08EJ | |
| 08F53AC9 | F602G08EJ | |
| 08F54AC | F602-08WJ | |
| 08F54AC1 | F602G08WJ | |
| 08F54AC9 | F602G08WJ | |
| 08F57AC | F602-08EJR | |
| 08F57AC1 | F602G08EJR | |
| 08F57AC9 | F602G08EJR | |
| 08F58AC | F602-08WJR | |
| 08F58AC1 | F602G08WJR | |
| 08F58AC9 | F602G08WJR | |
| 08F5GAC | F602-08EJ | |
| 08F5HAC | F602-08WJ | |
| 08F63AC | F602-10EJ | |
| 08F63AC9 | F602G10EJ | |
| 08F64AC | F602-10WJ | |
| 08F64AC9 | F602G10WJ | |
| 08F67AC | F602-10EJR | |
| 08F68AC | F602-10WJR | |
| 08F6GAC | F602-10EJ | |
| 08F6HAC | F602-10WJ | |
| 08F6HAC1 | F602G10WJ | |
| 08F73AC | F602-12EJ | |
| 08F73AC9 | F602G12EJ | |
| 08F74AC | F602-12WJ | |
| 08F74AC9 | F602G12WJ | |
| 08F77AC | F602-12EJR | |
| 08F77AC1 | F602G12EJR | |
| 08F77AC9 | F602G12EJR | |
| 08F78AC | F602-12WJR | |
| 08F78AC9 | F602G12WJR | |
| 08F7GAC | F602-12EJ | |
| 08F7HAC | F602-12WJ | |
| 08F43BC | F602-06EG | |
| 08F43BC1 | F602G06EG | |
| 08F43BC9 | F602G06EG | |
| 08F44BC | F602-06WG | |
| 08F44BC1 | F602G06WG | |
| 08F47BC | F602-06EGR | |
| 08F47BC1 | F602G06EGR | |
| 08F48BC | F602-06WGR | |
| 08F48BC1 | F602G06WGR | |
| 08F48BC9 | F602G06WGR | |
| 08F4GBC | F602-06EG | |
| 08F4HBC | F602-06WG | |
| 08F53BC | F602-08EG | |
| 08F53BC1 | F602G08EG | |
| 08F53BC9 | F602G08EG | |
| 08F54BC | F602-08WG | |
| 08F54BC1 | F602G08WG | |
| 08F54BC9 | F602G08WG | |
| 08F57BC | F602-08EGR | |
| 08F57BC1 | F602G08EGR | |
| 08F57BC9 | F602G08EGR | |

| 08 Series Part Number | General Line Replacement No. | Notes |
|----------------------------------|---|--------------|
| Filters | | |
| 08F58BC | F602-08WGR | |
| 08F58BC1 | F602G08WGR | |
| 08F58BC9 | F602G08WGR | |
| 08F5HBC | F602-08WG | |
| 08F63BC | F602-10EG | |
| 08F64BC | F602-10WG | |
| 08F64BC9 | F602G10WG | |
| 08F67BC | F602-10EGR | |
| 08F67BC1 | F602G10EGR | |
| 08F68BC | F602-10WGR | |
| 08F68BC1 | F602G10WGR | |
| 08F6HBC | F602-10WG | |
| 08F73BC | F602-12EG | |
| 08F73BC9 | F602G12EG | |
| 08F74BC | F602-12WG | |
| 08F74BC1 | F602G12WG | |
| 08F74BC9 | F602G12WG | |
| 08F77BC | F602-12EGR | |
| 08F77BC1 | F602G12EGR | |
| 08F78BC | F602-12WGR | |
| 08F78BC1 | F602G12WGR | |
| 08F78BC9 | F602G12WGR | |
| 08F7HBC | F602-12WG | |
| 08F43CC | F602-06EX46 | |
| 08F44CC | F602-06WX46 | |
| 08F47CC | F602-06ERX46 | |
| 08F48CC | F602-06WRX46 | |
| 08F53CC | F602-08EX46 | |
| 08F53CC9 | F602G08EX46 | |
| 08F54CC | F602-08WX46 | |
| 08F54CC9 | F602G08WX46 | |
| 08F57CC | F602-08ERX46 | |
| 08F58CC | F602-08WRX46 | |
| 08F58CC1 | F602G08WRX46 | |
| 08F63CC | F602-10EX46 | |
| 08F64CC | F602-10WX46 | |
| 08F67CC | F602-10ERX46 | |
| 08F68CC | F602-10WRX46 | |
| 08F73CC | F602-12EX46 | |
| 08F74CC | F602-12WX46 | |
| 08F77CC | F602-12ERX46 | |
| 08F78CC | F602-12WRX46 | |
| 08F53XC | F602-08EX11 | |
| 08F57XC | F602-08ERX11 | |
| 08F73XC | F602-12EX11 | |

| Coalescing Filters | | |
|---------------------------|-------------|--|
| 13F44ED | F701-06E3P | |
| 13F44ED1 | F701G06E3P | |
| 13F44EDN | F701G06E3 | |
| 13F44HD | F701-06E7P | |
| 13F44HDN | F701G06E7 | |
| 13F48ED | F701-06E3PT | |
| 13F48ED1 | F701G06E3PT | |
| 13F48EDN | F701G06E3T | |
| 13F48HD | F701-06E7PT | |
| 13F48HD1 | F701G06E7PT | |
| 13F4HED | F701-06E3P | |
| 13F4HHD | F701-06E7P | |
| 13F54ED | F701-08E3P | |
| 13F54ED1 | F701G08E3P | |
| 13F54ED9 | F701G08E3P | |
| 13F54EDN | F701G08E3 | |
| 13F54HD | F701-08E7P | |
| 13F54HDN | F701G08E7 | |

| <u>08 Series</u> <u>Part Number</u> | <u>General Line</u> <u>Replacement No.</u> | <u>Notes</u> |
|--|---|--------------|
|--|---|--------------|

Coalescing Filters

| | | |
|----------|-------------|--|
| 13F58ED | F701-08E3PT | |
| 13F58ED1 | F701G08E3PT | |
| 13F58ED9 | F701G08E3PT | |
| 13F58EDN | F701G08E3T | |
| 13F58HD | F701-08E7PT | |
| 13F58HD9 | F701G08E7PT | |
| 13F58HDN | F701G08E7T | |
| 13F5HED | F701-08E3P | |
| 13F5HHD | F701-08E7P | |

Regulators

| | | |
|-----------|------------|--|
| 08R411AB | R119-06C | |
| 08R411AB1 | R119G06C | |
| 08R411LB | R119-06CK | |
| 08R413AB | R119-06C | |
| 08R413AB1 | R119G06C | |
| 08R413AB9 | R119G06C | |
| 08R413LB | R119-06CK | |
| 08R415AB | R119-06D | |
| 08R415AB1 | R119G06D | |
| 08R415LB | R119-06DK | |
| 08R416AB | R119-06CG | |
| 08R416LB | R119-06CGK | |
| 08R418AB | R119-06CG | |
| 08R418AB1 | R119G06CG | |
| 08R418LB | R119-06CGK | |
| 08R421AB | R119-06DG | |
| 08R421LB | R119-06DGK | |
| 08R511AB | R119-08C | |
| 08R511AB1 | R119G08C | |
| 08R511AB9 | R119G08C | |
| 08R511LB | R119-08CK | |
| 08R511LB1 | R119G08CK | |
| 08R513AB | R119-08C | |
| 08R513AB1 | R119G08C | |
| 08R513AB9 | R119G08C | |
| 08R513LB | R119-08CK | |
| 08R515AB | R119-08D | |
| 08R515AB1 | R119G08D | |
| 08R515AB9 | R119G08D | |
| 08R515LB | R119-08DK | |
| 08R516AB | R119-08CG | |
| 08R516AB1 | R119G08CG | |
| 08R516LB | R119-08CGK | |
| 08R518AB | R119-08CG | |
| 08R518AB1 | R119G08CG | |
| 08R518AB9 | R119G08CG | |
| 08R518LB | R119-08CGK | |
| 08R521AB | R119-08DG | |
| 08R521AB9 | R119G08DG | |
| 08R521LB | R119-08DGK | |
| 08R611AB | R119-10C | |
| 08R611AB9 | R119G10C | |
| 08R611LB | R119-10CK | |
| 08R613AB | R119-10C | |
| 08R613AB1 | R119G10C | |
| 08R613AB9 | R119G10C | |
| 08R613LB | R119-10CK | |
| 08R615AB | R119-10D | |
| 08R615LB | R119-10DK | |
| 08R616AB | R119-10CG | |
| 08R616LB | R119-10CGK | |
| 08R618AB | R119-10CG | |
| 08R618AB1 | R119G10CG | |
| 08R618LB | R119-10CGK | |

| <u>08 Series</u> <u>Part Number</u> | <u>General Line</u> <u>Replacement No.</u> | <u>Notes</u> |
|--|---|--------------|
|--|---|--------------|

Regulators

| | | |
|-----------|------------|--------------------------|
| 08R621AB | R119-10DG | |
| 08R621AB1 | R119G10DG | |
| 08R621LB | R119-10DGK | |
| 08R711AB | R119-12C | |
| 08R711AB9 | R119G12C | |
| 08R711LB | R119-12CK | |
| 08R713AB | R119-12C | |
| 08R713AB1 | R119G12C | |
| 08R713AB9 | R119G12C | |
| 08R713LB | R119-12CK | |
| 08R715AB | R119-12D | |
| 08R715AB9 | R119G12D | |
| 08R715LB | R119-12DK | |
| 08R716AB | R119-12CG | |
| 08R716AB9 | R119G12CG | |
| 08R716LB | R119-12CGK | |
| 08R718AB | R119-12CG | |
| 08R718AB1 | R119G12CG | |
| 08R718AB9 | R119G12CG | |
| 08R718LB | R119-12CGK | |
| 08R721AB | R119-12DG | |
| 08R721AB9 | R119G12DG | |
| 08R721LB | R119-12DGK | |
| 13R414PB | R119-06JK | Pilot operated regulator |
| 13R415PB | R119-06J | Pilot operated regulator |
| 13R415PB9 | R119G06J | Pilot operated regulator |
| 13R421PB | R119-06JG | Pilot operated regulator |
| 13R421PB1 | R119G06JG | Pilot operated regulator |
| 13R514PB | R119-08JK | Pilot operated regulator |
| 13R515PB | R119-08J | Pilot operated regulator |
| 13R515PB1 | R119G08J | Pilot operated regulator |
| 13R515PB9 | R119G08J | Pilot operated regulator |
| 13R519PB | R119-08JGK | Pilot operated regulator |
| 13R521PB | R119-08JG | Pilot operated regulator |
| 13R521PB1 | R119G08JG | Pilot operated regulator |
| 13R614PB | R119-10JK | Pilot operated regulator |
| 13R615PB | R119-10J | Pilot operated regulator |
| 13R615PB9 | R119G10J | Pilot operated regulator |
| 13R621PB | R119-10JG | Pilot operated regulator |
| 13R621PB1 | R119G10JG | Pilot operated regulator |
| 13R714PB | R119-12JK | Pilot operated regulator |
| 13R715PB | R119-12J | Pilot operated regulator |
| 13R715PB9 | R119G12J | Pilot operated regulator |
| 13R719PB | R119-12JGK | Pilot operated regulator |
| 13R721PB | R119-12JG | Pilot operated regulator |
| 13R721PB1 | R119G12JG | Pilot operated regulator |

Lubricators

| | | |
|-----------|-----------|--|
| 08L44AC | L606-06W | |
| 08L44BC | L606-06W | |
| 08L44BC1 | L606G06W | |
| 08L44BC9 | L606G06W | |
| 08L44BCSB | L606G06W | |
| 08L44EC | L606-06WH | |
| 08L44FC | L606-06WH | |
| 08L48AC | L606-06W | |
| 08L48AC9 | L606G06W | |
| 08L48BC | L606-06W | |
| 08L4MAC | L606-06WJ | |
| 08L4MBC | L606-06WJ | |
| 08L53BC | L606-08E | |
| 08L54AC | L606-08W | |
| 08L54AC1 | L606G08W | |
| 08L54AC9 | L606G08W | |
| 08L54BC | L606-08W | |

| 08 Series Part Number | General Line Replacement No. | Notes |
|----------------------------------|---|------------------------------|
| Lubricators | | |
| 08L54BC1 | L606G08W | |
| 08L54BC9 | L606G08W | |
| 08L54EC | L606-08WH | |
| 08L54EC1 | L606G08WH | |
| 08L54FC | L606-08WH | |
| 08L54FC1 | L606G08WH | |
| 08L58AC | L606-08W | |
| 08L58BC | L606-08W | |
| 08L58BC1 | L606G08W | |
| 08L5MBC | L606-08WJ | |
| 08L64AC | L606-10W | |
| 08L64BC | L606-10W | |
| 08L64BC9 | L606G10W | |
| 08L64BCSB | L606G10W | |
| 08L64FC | L606-10WH | |
| 08L68AC | L606-10W | |
| 08L68BC | L606-10W | |
| 08L6MAC | L606-10WJ | |
| 08L6MBC | L606-10WJ | |
| 08L74AC | L606-12W | |
| 08L74BC | L606-12W | |
| 08L74BC1 | L606G12W | |
| 08L74BC9 | L606G12W | |
| 08L74EC | L606-12WH | |
| 08L74FC | L606-12WH | |
| 08L78BC | L606-12W | |
| 08L7MBC | L606-12WJ | |
| 18L44AC | L606-06W | Is not Micro Mist lubricator |
| 18L44BC | L606-06W | Is not Micro Mist lubricator |
| 18L44BC9 | L606G06W | Is not Micro Mist lubricator |
| 18L44EC | L606-06WH | Is not Micro Mist lubricator |
| 18L44FC | L606-06WH | Is not Micro Mist lubricator |
| 18L48AC | L606-06W | Is not Micro Mist lubricator |
| 18L48BC | L606-06W | Is not Micro Mist lubricator |
| 18L4MAC | L606-06WJ | Is not Micro Mist lubricator |
| 18L4MBC | L606-06WJ | Is not Micro Mist lubricator |
| 18L54AC | L606-08W | Is not Micro Mist lubricator |
| 18L54AC1 | L606G08W | Is not Micro Mist lubricator |
| 18L54BC | L606-08W | Is not Micro Mist lubricator |
| 18L54BC1 | L606G08W | Is not Micro Mist lubricator |
| 18L54BC9 | L606G08W | Is not Micro Mist lubricator |
| 18L54EC | L606-08WH | Is not Micro Mist lubricator |
| 18L54FC | L606-08WH | Is not Micro Mist lubricator |
| 18L54FC1 | L606G08WH | Is not Micro Mist lubricator |
| 18L54FC9 | L606G08WH | Is not Micro Mist lubricator |
| 18L58AC | L606-08W | Is not Micro Mist lubricator |
| 18L58BC | L606-08W | Is not Micro Mist lubricator |
| 18L5MBC | L606-08WJ | Is not Micro Mist lubricator |
| 18L64AC | L606-10W | Is not Micro Mist lubricator |
| 18L64BC | L606-10W | Is not Micro Mist lubricator |
| 18L64BC1 | L606G10W | Is not Micro Mist lubricator |
| 18L64BC9 | L606G10W | Is not Micro Mist lubricator |
| 18L64FC | L606-10WH | Is not Micro Mist lubricator |
| 18L68AC | L606-10W | Is not Micro Mist lubricator |
| 18L68BC | L606-10W | Is not Micro Mist lubricator |
| 18L6MBC | L606-10WJ | Is not Micro Mist lubricator |
| 18L74AC | L606-12W | Is not Micro Mist lubricator |
| 18L74BC | L606-12W | Is not Micro Mist lubricator |
| 18L74BC9 | L606G12W | Is not Micro Mist lubricator |
| 18L74EC | L606-12WH | Is not Micro Mist lubricator |
| 18L74FC | L606-12WH | Is not Micro Mist lubricator |
| 18L74FC9 | L606G12WH | Is not Micro Mist lubricator |
| 18L78AC | L606-12W | Is not Micro Mist lubricator |
| 18L78BC | L606-12W | Is not Micro Mist lubricator |
| 18L7MBC | L606-12WJ | Is not Micro Mist lubricator |

| 08 Series Part Number | General Line Replacement No. | Notes |
|----------------------------------|---|---------------------------|
| Combinations | | |
| 08A43A13A4BC | C628-06FRLEJWCW | Gauges standard with unit |
| 08A43A13A4EC | C628-06FRLEJWCWH | Gauges standard with unit |
| 08A43A13A4FC | C628-06FRLEJWCWH | Gauges standard with unit |
| 08A43A13A8BC | C628-06FRLEJWCW | Gauges standard with unit |
| 08A43A15A4BC | C628-06FRLEJDW | Gauges standard with unit |
| 08A43A18A4BC | C628-06FRLEJWCW | Gauges standard with unit |
| 08A43B13A4FC | C628-06FRLEGCWH | Gauges standard with unit |
| 08A43B18A4AC | C628-06FRLEGCW | Gauges standard with unit |
| 08A44A13A4BC | C628-06FRLWJCW | Gauges standard with unit |
| 08A44A15A4BC | C628-06FRLWJDW | Gauges standard with unit |
| 08A44A18A4AC | C628-06FRLWJCW | Gauges standard with unit |
| 08A44A18A4BC | C628-06FRLWJCW | Gauges standard with unit |
| 08A44B13A4BC | C628-06FRLWGCW | Gauges standard with unit |
| 08A47A13A4BC | C628-06FRLEJWCWR | Gauges standard with unit |
| 08A47A18A4BC | C628-06FRLEJWCWR | Gauges standard with unit |
| 08A47B13A4EC | C628-06FRLEGCWHR | Gauges standard with unit |
| 08A47B18A4BC | C628-06FRLEGCWR | Gauges standard with unit |
| 08A48A13A4AC | C628-06FRLWJCWR | Gauges standard with unit |
| 08A48A13A4BC | C628-06FRLWJCWR | Gauges standard with unit |
| 08A48A13A4FC | C628-06FRLWJCWHR | Gauges standard with unit |
| 08A48A13A8AC | C628-06FRLWJCWR | Gauges standard with unit |
| 08A48A13A8BC | C628-06FRLWJCWR | Gauges standard with unit |
| 08A48A18A4BC | C628-06FRLWJCWR | Gauges standard with unit |
| 08A48B13A4BC | C628-06FRLWGCWR | Gauges standard with unit |
| 08A48B13A4EC | C628-06FRLWGCWHR | Gauges standard with unit |
| 08A48B18A4AC | C628-06FRLWGCWR | Gauges standard with unit |
| 08A4HA18A4BC | C628-06FRLWJCW | Gauges standard with unit |
| 08A4HA21A4BC | C628-06FRLWJDW | Gauges standard with unit |
| 08A4HB18A4AC | C628-06FRLWGCW | Gauges standard with unit |
| 08A53A11A4BC | C628-08FRLEJWCW | Gauges standard with unit |
| 08A53A13A4AC | C628-08FRLEJWCW | Gauges standard with unit |
| 08A53A13A4BC | C628-08FRLEJWCW | Gauges standard with unit |
| 08A53A13A4EC | C628-08FRLEJWCWH | Gauges standard with unit |
| 08A53A13A8BC | C628-08FRLEJWCW | Gauges standard with unit |
| 08A53A15A8BC | C628-08FRLEJDW | Gauges standard with unit |
| 08A53A18A4BC | C628-08FRLEJWCW | Gauges standard with unit |
| 08A53A18A4EC | C628-08FRLEJWCWH | Gauges standard with unit |
| 08A53A21A4BC | C628-08FRLEJDW | Gauges standard with unit |
| 08A53B13A4FC | C628-08FRLEGCWH | Gauges standard with unit |
| 08A53B18A4BC | C628-08FRLEGCW | Gauges standard with unit |
| 08A54A13A4BC | C628-08FRLWJCW | Gauges standard with unit |
| 08A54A13A8BC | C628-08FRLWJCW | Gauges standard with unit |
| 08A54A15A4AC | C628-08FRLWJDW | Gauges standard with unit |
| 08A54A18A4AC | C628-08FRLWJCW | Gauges standard with unit |
| 08A54A18A4BC | C628-08FRLWJCW | Gauges standard with unit |
| 08A54A18A4BC9 | C628G08FRLWJCW | Gauges standard with unit |
| 08A54A18A4EC | C628-08FRLWJCWH | Gauges standard with unit |
| 08A54A21A4BC | C628-08FRLWJDW | Gauges standard with unit |
| 08A54B13A4BC | C628-08FRLWGCW | Gauges standard with unit |
| 08A54B18A4BC | C628-08FRLWGCW | Gauges standard with unit |
| 08A57A13A4BC | C628-08FRLEJWCWR | Gauges standard with unit |
| 08A57A13A8BC | C628-08FRLEJWCWR | Gauges standard with unit |
| 08A57A13AMAC | C628-08FRLEJWCWR | Gauges standard with unit |
| 08A57A15A4BC | C628-08FRLEJDWR | Gauges standard with unit |
| 08A57A18A4BC | C628-08FRLEJWCWR | Gauges standard with unit |
| 08A57B13A4BC | C628-08FRLEGCWR | Gauges standard with unit |
| 08A57B13A4EC | C628-08FRLEGCWHR | Gauges standard with unit |
| 08A57B13A8AC | C628-08FRLEGCWR | Gauges standard with unit |
| 08A57B18A4BC | C628-08FRLEGCWR | Gauges standard with unit |
| 08A57B21A8BC | C628-08FRLEGDWR | Gauges standard with unit |
| 08A58A13A4AC | C628-08FRLWJCWR | Gauges standard with unit |
| 08A58A13A4BC | C628-08FRLWJCWR | Gauges standard with unit |
| 08A58A13A4EC | C628-08FRLWJCWHR | Gauges standard with unit |
| 08A58A13A8AC | C628-08FRLWJCWR | Gauges standard with unit |

| 08 Series Part Number | General Line Replacement No. | Notes | 08 Series Part Number | General Line Replacement No. | Notes |
|-----------------------|------------------------------|---|-----------------------|------------------------------|---|
| Combinations | | | Combinations | | |
| 08A58A13A8BC | C628-08FRLWJCWR | Gauges standard with unit | 18A43A16A4AC | C628-06FRLEJJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58A13AMAC | C628-08FRLWJCWJR | Gauges standard with unit | 18A43A18A4BC | C628-06FRLEJJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58A18A4AC | C628-08FRLWJCWR | Gauges standard with unit | 18A43A18A4EC | C628-06FRLEJJCWH | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58A18A4BC | C628-08FRLWJCWR | Gauges standard with unit | 18A43A21A4BC | C628-06FRLEJDW | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58A18A4BC9 | C628G08FRLWJCWR | Gauges standard with unit | 18A43B18A4FC | C628-06FRLEGCWH | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58A18A4FC | C628-08FRLWJCWHR | Gauges standard with unit | 18A44A13A4BC | C628-06FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58A18A8BC | C628-08FRLWJCWR | Gauges standard with unit | 18A44A18A4BC | C628-06FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58A21A4AC | C628-08FRLWJDWR | Gauges standard with unit | 18A44A21A4BC | C628-06FRLWJDW | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58A21A4BC | C628-08FRLWJDWR | Gauges standard with unit | 18A44B13A4BC | C628-06FRLWGCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58B13A4BC | C628-08FRLWGCWR | Gauges standard with unit | 18A47A13A4BC | C628-06FRLEJJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58B13A4EC | C628-08FRLWGCWHR | Gauges standard with unit | 18A47A13A8BC | C628-06FRLEJJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58B13LMBC | C628-08FRLWGCWJKR | Gauges standard with unit | 18A47A15A4BC | C628-06FRLEJDWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58B18A4AC | C628-08FRLWGCWR | Gauges standard with unit | 18A47A18A4BC | C628-06FRLEJJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A58B18A8BC | C628-08FRLWGCWR | Gauges standard with unit | 18A47A21A4BC | C628-06FRLEJDWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A5HA18A8BC | C628-08FRLWJCW | Gauges standard with unit | 18A47B13A4BC | C628-06FRLEGCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A63A13A4BC | C628-10FRLEJJCW | Gauges standard with unit | 18A48A13A4BC | C628-06FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A63A18A4BC | C628-10FRLEJJCW | Gauges standard with unit | 18A48A13A4FC | C628-06FRLWJCWHR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A64A13A4BC | C628-10FRLWJCWHK | Gauges standard with unit | 18A48A13A8BC | C628-06FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A64A16A4BC | C628-10FRLWJCW | Gauges standard with unit | 18A48A18A4AC | C628-06FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A64A18A4BC | C628-10FRLWJCW | Gauges standard with unit | 18A48A18A4BC | C628-06FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A64A18A4BC9 | C628G10FRLWJCW | Gauges standard with unit | 18A48A18A4FC | C628-06FRLWJCWHR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A64A18L4BC | C628-10FRLWJCWK | Gauges standard with unit | 18A48A18A8BC | C628-06FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A64A21A4BC9 | C628G10FRLWJDW | Gauges standard with unit | 18A48B13A4AC | C628-06FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 08A64A21A4EC | C628-10FRLWJDWH | Gauges standard with unit | | | |
| 08A64B18L4BC | C628-10FRLWGCWK | Gauges standard with unit | | | |
| 08A67A18A4BC | C628-10FRLEJJCWR | Gauges standard with unit | | | |
| 08A67B13A4EC | C628-10FRLEGCWHR | Gauges standard with unit | | | |
| 08A68A13A4BC | C628-10FRLWJCWR | Gauges standard with unit | | | |
| 08A68A13A8BC | C628-10FRLWJCWR | Gauges standard with unit | | | |
| 08A68A15A4BC | C628-10FRLWJDWR | Gauges standard with unit | | | |
| 08A68A18A4BC | C628-10FRLWJCWR | Gauges standard with unit | | | |
| 08A68A21A4BC9 | C628G10FRLWJDWR | Gauges standard with unit | | | |
| 08A68B13A4EC | C628-10FRLWGCWHR | Gauges standard with unit | | | |
| 08A68B18A4AC | C628-10FRLWGCWR | Gauges standard with unit | | | |
| 08A68B21A4BC | C628-10FRLWGDWR | Gauges standard with unit | | | |
| 08A73A13A4BC | C628-12FRLEJJCW | Gauges standard with unit | | | |
| 08A73A18A4BC | C628-12FRLEJJCW | Gauges standard with unit | | | |
| 08A74A13A4BC | C628-12FRLWJCW | Gauges standard with unit | | | |
| 08A74A15A4AC | C628-12FRLWJDW | Gauges standard with unit | | | |
| 08A74A16A4BC | C628-12FRLWJCW | Gauges standard with unit | | | |
| 08A74A18A4BC | C628-12FRLWJCW | Gauges standard with unit | | | |
| 08A74A18A4BC9 | C628G12FRLWJCW | Gauges standard with unit | | | |
| 08A77A13A8BC | C628-12FRLEJJCWR | Gauges standard with unit | | | |
| 08A77A18A4BC | C628-12FRLEJJCWR | Gauges standard with unit | | | |
| 08A77B21A8BC | C628-12FRLEGDWR | Gauges standard with unit | | | |
| 08A78A18A4BC | C628-12FRLWJCWR | Gauges standard with unit | | | |
| 08A78B13A4BC | C628-12FRLWGCWR | Gauges standard with unit | | | |
| 08A78B18A4AC | C628-12FRLWGCWR | Gauges standard with unit | | | |
| 08A7HA18A4BC | C628-12FRLWJCW | Gauges standard with unit | | | |
| 18A43A13A4AC | C628-06FRLEJJCW | Does not have Micro Mist lubricator / gauges standard with unit | | | |
| 18A43A13A4BC | C628-06FRLEJJCW | Does not have Micro Mist lubricator / gauges standard with unit | | | |
| 18A43A13A8AC | C628-06FRLEJJCW | Does not have Micro Mist lubricator / gauges standard with unit | | | |
| 18A43A13A8BC | C628-06FRLEJJCW | Does not have Micro Mist lubricator / gauges standard with unit | | | |
| 18A43A13L4FC | C628-06FRLEJJCWHK | Does not have Micro Mist lubricator / gauges standard with unit | | | |

| <u>08 Series Part Number</u> | <u>General Line Replacement No.</u> | <u>Notes</u> |
|------------------------------|-------------------------------------|---|
| Combinations | | |
| 18A48B13A4BC | C628-06FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A48B18A4AC | C628-06FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A4GB13A4AC | C628-06FRLEGW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A53A13A4BC | C628-08FRLEJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A53A15A8BC | C628-08FRLEJDW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A53A18A4AC | C628-08FRLEJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A53A18A4BC | C628-08FRLEJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A53A18L4BC | C628-08FRLEJCWK | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A53A21A4BC | C628-08FRLEJDW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A53A21A8BC | C628-08FRLEJDW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A53B13A4BC | C628-08FRLEGW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A53B18A4BC | C628-08FRLEGW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54A13A4AC | C628-08FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54A13A4BC | C628-08FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54A13A4BC1 | C628G08FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54A18A4AC | C628-08FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54A18A4BC | C628-08FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54A18A8BC | C628-08FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54A18AMBC | C628-08FRLWJCWJ | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54B13A4BC | C628-08FRLWGCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54B18A4AC | C628-08FRLWGCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54B18A4BC | C628-08FRLWGCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A54B18A4BC1 | C628G08FRLWGCW | Does not have Micro Mist lubricator / gauges standard with unit |

| <u>08 Series Part Number</u> | <u>General Line Replacement No.</u> | <u>Notes</u> |
|------------------------------|-------------------------------------|---|
| Combinations | | |
| 18A57A11A4BC | C628-08FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A57A13A4AC | C628-08FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A57A13A4BC | C628-08FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A57A13A4FC | C628-08FRLEJCWHR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A57A13A8BC | C628-08FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A57A15A4BC | C628-08FRLEJDWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A57A18A4BC | C628-08FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A57A18A8BC | C628-08FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A57A21A4AC | C628-08FRLEJDWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A57B13A4BC | C628-08FRLEGW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A57B18A4BC | C628-08FRLEGW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A58A13A4BC | C628-08FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A58A13AMBC | C628-08FRLWJCWJR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A58A18A4BC | C628-08FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A58B13A4BC | C628-08FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A58B18A4AC | C628-08FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A58B18A4BC | C628-08FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A5GA13A4BC | C628-08FRLEJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A5HB18A4BC | C628-08FRLWGCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A5HB18A8BC | C628-08FRLWGCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A63A13A4BC | C628-10FRLEJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A63A18A4BC | C628-10FRLEJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A63B13A4FC | C628-10FRLEGW | Does not have Micro Mist lubricator / gauges standard with unit |

| <u>08 Series Part Number</u> | <u>General Line Replacement No.</u> | <u>Notes</u> | <u>08 Series Part Number</u> | <u>General Line Replacement No.</u> | <u>Notes</u> |
|------------------------------|-------------------------------------|---|------------------------------|-------------------------------------|---|
| Combinations | | | Combinations | | |
| 18A64A13A4BC | C628-10FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit | 18A73A21A4BC | C628-12FRLEJDW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A64A13A4EC | C628-10FRLWJCWH | Does not have Micro Mist lubricator / gauges standard with unit | 18A73B13A4BC | C628-12FRLEGCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A64A13A4FC | C628-10FRLWJCWH | Does not have Micro Mist lubricator / gauges standard with unit | 18A74A13A4EC | C628-12FRLWJCWH | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A64A18A4BC | C628-10FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit | 18A74A16A4AC | C628-12FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A64A18AMBC | C628-10FRLWJCWJ | Does not have Micro Mist lubricator / gauges standard with unit | 18A74A18A4AC | C628-12FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A64B13A4BC | C628-10FRLWGCW | Does not have Micro Mist lubricator / gauges standard with unit | 18A74A18A4BC | C628-12FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A64B18A4BC1 | C628G10FRLWGCW | Does not have Micro Mist lubricator / gauges standard with unit | 18A74A18A4BC9 | C628G12FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A67A13A4AC | C628-10FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A74B18A4BC | C628-12FRLWGCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A67A13A4EC | C628-10FRLEJCWHR | Does not have Micro Mist lubricator / gauges standard with unit | 18A77A13A4BC | C628-12FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A67A18A4AC | C628-10FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A77A13A4EC | C628-12FRLEJCWHR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A67A18A4BC | C628-10FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A77A18A4BC | C628-12FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A67A18A8BC | C628-10FRLEJCWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A77B18A4BC | C628-12FRLEGCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A67B21A4FC | C628-10FRLEGDWHR | Does not have Micro Mist lubricator / gauges standard with unit | 18A78A13A4BC | C628-12FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A68A13A4BC | C628-10FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A78A18A4AC | C628-12FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A68A15A4BC | C628-10FRLWJDWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A78A18A4BC | C628-12FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A68A16A4BC | C628-10FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A78B13A4BC | C628-12FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A68A18A4BC | C628-10FRLWJCWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A78B18A4AC | C628-12FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A68B13A4BC | C628-10FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A78B21AMAC | C628-12FRLWGDWJR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A68B18A4AC | C628-10FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A78B21L8BC | C628-12FRLWGDWKR | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A68B18A4BC | C628-10FRLWGCWR | Does not have Micro Mist lubricator / gauges standard with unit | 18A7GA18A4BC | C628-12FRLEJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A6HA18A4BC | C628-10FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit | 18A7HA18A4FC | C628-12FRLWJCWH | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A73A13A4BC | C628-12FRLEJCW | Does not have Micro Mist lubricator / gauges standard with unit | 18A7HA18A8BC | C628-12FRLWJCW | Does not have Micro Mist lubricator / gauges standard with unit |
| 18A73A18A4BC | C628-12FRLEJCW | Does not have Micro Mist lubricator / gauges standard with unit | 18A7HA21A4BC | C628-12FRLWJDW | Does not have Micro Mist lubricator / gauges standard with unit |



Parker Hannifin Corporation
Pneumatic Division
8676 E. M89
P.O. Box 901
Richland, MI 49083 USA
Tel: (269) 629-5000
Fax: (269) 629-5385

Customer/Technical Service

Tel: (269) 629-5575
Fax: (269) 629-5385
Web site: www.parker.com/pneumatic
E-mail: PDNMKTG@parker.com