



**Pneumatic Division North America**  
 Richland, Michigan 49083

**FRL-SIF-72**

**Cross-Reference of Prep-Air® II  
 “08” to “P3N” Model Numbers**

**ISSUED: February, 2000**

**Supersedes: January, 2000**

# Cross-Reference of Prep-Air® II “08” to “P3N” Model Numbers

“08” Model No.	“P3N” Model No.	Notes
08A43A13A4BC ...	P3NCB96SGMNNLNA ...	Uses metal bowl w/ sight gauge
08A43A13A4EC ...	P3NCB96SGMNNLHA ...	Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
08A43A13A4FC ...	P3NCB96SGMNNLHA ...	Uses metal bowl w/ sight gauge
08A43A13A8BC ...	P3NCB96SGMNNLSA ...	Uses metal bowl w/ sight gauge
08A43A15A4BC ...	P3NCB96SGMNNLNA ...	Uses metal bowl w/ sight gauge
08A43A18A4BC ...	P3NCB96SGMNNLNA ...	Uses metal bowl w/ sight gauge
08A43B13A4FC ...	P3NCB96SEMNNLHA ...	Uses metal bowl w/ sight gauge
08A43B18A4AC ...	P3NCB96SEMNNLNA ...	Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
08A44A13A4BC ...	P3NCB96SGMNNLNA	
08A44A15A4BC ...	P3NCB96SGMNNLNA	
08A44A18A4AC ...	P3NCB96SGMNNLNA ...	Tamper Resistant Knob is Standard
08A44A18A4BC ...	P3NCB96SGMNNLNA	
08A44B13A4BC ...	P3NCB96SEMNNLNA	
08A47A13A4BC ...	P3NCB96SGANNNLNA ...	Uses metal bowl w/ sight gauge
08A47A18A4BC ...	P3NCB96SGANNNLNA ...	Uses metal bowl w/ sight gauge
08A47B13A4EC ...	P3NCB96SEANNNLHA ...	Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
08A47B18A4BC ...	P3NCB96SEANNNLNA ...	Uses metal bowl w/ sight gauge
08A48A13A4AC ...	P3NCB96SGANNNLNA ...	Tamper Resistant Knob is Standard
08A48A13A4BC ...	P3NCB96SGANNNLNA	
08A48A13A4FC ...	P3NCB96SGANNNLHA	
08A48A13A8AC ...	P3NCB96SGANNNLSA ...	Tamper Resistant Knob is Standard
08A48A13A8BC ...	P3NCB96SGANNNLSA	
08A48A18A4BC ...	P3NCB96SGANNNLNA	
08A48B13A4BC ...	P3NCB96SEANNNLNA	
08A48B13A4EC ...	P3NCB96SEANNNLHA ...	Tamper Resistant Knob is Standard
08A48B18A4AC ...	P3NCB96SEANNNLNA ...	Tamper Resistant Knob is Standard
08A4HA18A4BC ...	P3NCB96SGPNGLNA	
08A4HA21A4BC ...	P3NCB96SGPNJLNA	
08A4HB18A4AC ...	P3NCB96SEPGLNA ...	Tamper Resistant Knob is Standard
08A53A11A4BC ...	P3NCB98SGMNNLNA ...	Uses metal bowl w/ sight gauge
08A53A13A4AC ...	P3NCB98SGMNNLNA ...	Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
08A53A13A4BC ...	P3NCB98SGMNNLNA ...	Uses metal bowl w/ sight gauge
08A53A13A4EC ...	P3NCB98SGMNNLHA ...	Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
08A53A13A8BC ...	P3NCB98SGMNNLSA ...	Uses metal bowl w/ sight gauge

“08” Model No.	“P3N” Model No.	Notes
08A53A15A8BC ...	P3NCB98SGMNNLSA ...	Uses metal bowl w/ sight gauge
08A53A18A4BC ...	P3NCB98SGMNNLNA ...	Uses metal bowl w/ sight gauge
08A53A18A4EC ...	P3NCB98SGMNNLHA ...	Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
08A53A21A4BC ...	P3NCB98SGMNNLNA ...	Uses metal bowl w/ sight gauge
08A53B13A4FC ...	P3NCB98SEMNNLHA ...	Uses metal bowl w/ sight gauge
08A53B18A4BC ...	P3NCB98SEMNNLNA ...	Uses metal bowl w/ sight gauge
08A54A13A4BC ...	P3NCB98SGMNNLNA	
08A54A13A8BC ...	P3NCB98SGMNNLSA	
08A54A15A4AC ...	P3NCB98SGMNNLNA ...	Tamper Resistant Knob is Standard
08A54A18A4AC ...	P3NCB98SGMNNLNA ...	Tamper Resistant Knob is Standard
08A54A18A4BC ...	P3NCB98SGMNNLNA	
08A54A18A4BC9 .	P3NCB18SGMNNLNA	
08A54A18A4EC ...	P3NCB98SGMNNLHA ...	Tamper Resistant Knob is Standard
08A54A21A4BC ...	P3NCB98SGMNNLNA	
08A54B13A4BC ...	P3NCB98SEMNNLNA	
08A54B18A4BC ...	P3NCB98SEMNNLNA	
08A57A13A4BC ...	P3NCB98SGANNNLNA ...	Uses metal bowl w/ sight gauge
08A57A13A8BC ...	P3NCB98SGANNNLSA ...	Uses metal bowl w/ sight gauge
08A57A13AMAC ..	P3NCB98SGANNNLAA ...	Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
08A57A15A4BC ...	P3NCB98SGANNNLNA ...	Uses metal bowl w/ sight gauge
08A57A18A4BC ...	P3NCB98SGANNNLNA ...	Uses metal bowl w/ sight gauge
08A57B13A4BC ...	P3NCB98SEANNNLNA ...	Uses metal bowl w/ sight gauge
08A57B13A4EC ...	P3NCB98SEANNNLHA ...	Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
08A57B13A8AC ...	P3NCB98SEANNNLSA ...	Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
08A57B18A4BC ...	P3NCB98SEANNNLNA ...	Uses metal bowl w/ sight gauge
08A57B21A8BC ...	P3NCB98SEANNNLSA ...	Uses metal bowl w/ sight gauge
08A58A13A4AC ...	P3NCB98SGANNNLNA ...	Tamper Resistant Knob is Standard
08A58A13A4BC ...	P3NCB98SGANNNLNA	
08A58A13A4EC ...	P3NCB98SGANNNLHA ...	Tamper Resistant Knob is Standard
08A58A13A8AC ...	P3NCB98SGANNNLSA ...	Tamper Resistant Knob is Standard
08A58A13A8BC ...	P3NCB98SGANNNLSA	
08A58A13AMAC ..	P3NCB98SGANNNLAA ...	Tamper Resistant Knob is Standard
08A58A18A4AC ...	P3NCB98SGANNNLNA ...	Tamper Resistant Knob is Standard
08A58A18A4BC ...	P3NCB98SGANNNLNA	
08A58A18A4BC9 .	P3NCB18SGANNNLNA	

“08” Model No.	“P3N” Model No.	Notes
08A58A18A4FC ...	P3NCB98SGANGLHA	
08A58A18A8BC ...	P3NCB98SGANGLSA	
08A58A21A4AC ...	P3NCB98SGANJLNA ....	Tamper Resistant Knob is Standard
08A58A21A4BC ...	P3NCB98SGANJLNA	
08A58B13A4BC ...	P3NCB98SEANNLNA	
08A58B13A4EC ...	P3NCB98SEANNLHA ....	Tamper Resistant Knob is Standard
08A58B13LMBC ...	P3NCB98SEAMNLAA	
08A58B18A4AC ...	P3NCB98SEANGLNA ....	Tamper Resistant Knob is Standard
08A58B18A8BC ...	P3NCB98SEANGLSA	
08A5HA18A8BC ...	P3NCB98SGPNGLSA	
08A63A13A4BC ...	P3NCB9PSGMNMLNA ...	Uses metal bowl w/ sight gauge, Uses 1-1/2" port
08A63A18A4BC ...	P3NCB9PSGMNGLNA ...	Uses metal bowl w/ sight gauge, Uses 1-1/2" port
08A64A13A4BC ...	P3NCB9PSGMNMLNA ...	Uses 1-1/2" port
08A64A13L4FC ...	P3NCB9PSGMNMLHA ..	Uses 1-1/2" port
08A64A16A4BC ...	P3NCB9PSGMNMLNA ..	Uses 1-1/2" port
08A64A18A4BC ...	P3NCB9PSGMNGLNA ...	Uses 1-1/2" port
08A64A18A4BC9 ..	P3NCB1PSGMNGLNA ...	Uses 1-1/2" port
08A64A18L4BC ...	P3NCB9PSGMMLNA ..	Uses 1-1/2" port
08A64A21A4BC9 ..	P3NCB1PSGMNMLNA ...	Uses 1-1/2" port
08A64A21A4EC ...	P3NCB9PSGMNMLHA ...	Tamper Resistant Knob is Standard, Uses 1-1/2" port
08A64B18L4BC ...	P3NCB9PSEMMGLNA ..	Uses 1-1/2" port
08A67A18A4BC ...	P3NCB9PSGANGLNA ...	Uses metal bowl w/ sight gauge, Uses 1-1/2" port
08A67B13A4EC ...	P3NCB9PSEANNLHA ....	Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard, Uses 1-1/2" port
08A68A13A4BC ...	P3NCB9PSGANLNA ...	Uses 1-1/2" port
08A68A13A8BC ...	P3NCB9PSGANLNSA ....	Uses 1-1/2" port
08A68A15A4BC ...	P3NCB9PSGANHLNA ...	Uses 1-1/2" port
08A68A18A4BC ...	P3NCB9PSGANGLNA ...	Uses 1-1/2" port
08A68A21A4BC9 ..	P3NCB1PSGANJLNA ....	Uses 1-1/2" port
08A68B13A4EC ...	P3NCB9PSEANNLHA ....	Tamper Resistant Knob is Standard, Uses 1-1/2" port
08A68B18A4AC ...	P3NCB9PSEANGLNA ....	Tamper Resistant Knob is Standard, Uses 1-1/2" port
08A68B21A4BC ...	P3NCB9PSEANJLNA .....	Uses 1-1/2" port
08A73A13A4BC ...	P3NCB9PSGMNMLNA ...	Uses metal bowl w/ sight gauge
08A73A18A4BC ...	P3NCB9PSGMNGLNA ...	Uses metal bowl w/ sight gauge
08A74A13A4BC ...	P3NCB9PSGMNMLNA	
08A74A15A4AC ...	P3NCB9PSGMNHLNA ...	Tamper Resistant Knob is Standard
08A74A16A4BC ...	P3NCB9PSGMNMLNA	
08A74A18A4BC ...	P3NCB9PSGMNGLNA	
08A74A18A4BC9 ..	P3NCB1PSGMNGLNA	
08A77A13A8BC ...	P3NCB9PSGANLNSA ....	Uses metal bowl w/ sight gauge
08A77A18A4BC ...	P3NCB9PSGANGLNA ...	Uses metal bowl w/ sight gauge
08A77B21A8BC ...	P3NCB9PSEANJLSA .....	Uses metal bowl w/ sight gauge
08A78A18A4BC ...	P3NCB9PSGANGLNA	
08A78B13A4BC ...	P3NCB9PSEANNLNA	
08A78B18A4AC ...	P3NCB9PSEANGLNA ....	Tamper Resistant Knob is Standard
08A7HA18A4BC ...	P3NCB9PSGPNGLSA	
08F43AC .....	P3NFA96GSM .....	Uses metal bowl w/ sight gauge

“08” Model No.	“P3N” Model No.	Notes
08F43AC1 .....	P3NFA16GSM .....	Uses metal bowl w/ sight gauge
08F43AC9 .....	P3NFA16GSM .....	Uses metal bowl w/ sight gauge
08F43BC .....	P3NFA96ESM .....	Uses metal bowl w/ sight gauge
08F43BC1 .....	P3NFA16ESM .....	Uses metal bowl w/ sight gauge
08F43BC9 .....	P3NFA16ESM .....	Uses metal bowl w/ sight gauge
08F43CC .....	P3NFA96JSM .....	Uses metal bowl w/ sight gauge
08F43ZC .....	P3NFA96ASM .....	Uses metal bowl w/ sight gauge
08F44AC .....	P3NFA96GSM	
08F44AC1 .....	P3NFA16GSM	
08F44AC9 .....	P3NFA16GSM	
08F44BC .....	P3NFA96ESM	
08F44BC1 .....	P3NFA16ESM	
08F44CC .....	P3NFA96JSM	
08F47AC .....	P3NFA96GSA .....	Uses metal bowl w/ sight gauge
08F47BC .....	P3NFA96ESA .....	Uses metal bowl w/ sight gauge
08F47BC1 .....	P3NFA16ESA .....	Uses metal bowl w/ sight gauge
08F47CC .....	P3NFA96JSA .....	Uses metal bowl w/ sight gauge
08F47ZC .....	P3NFA96ASA .....	Uses metal bowl w/ sight gauge
08F48AC .....	P3NFA96GSA	
08F48AC1 .....	P3NFA16GSA	
08F48BC .....	P3NFA96ESA	
08F48BC1 .....	P3NFA16ESA	
08F48BC9 .....	P3NFA16ESA	
08F48CC .....	P3NFA96JSA	
08F48ZC .....	P3NFA96ASA	
08F4GAC .....	P3NFA96GSP .....	Uses metal bowl w/ sight gauge
08F4GBC .....	P3NFA96ESP .....	Uses metal bowl w/ sight gauge
08F4HAC .....	P3NFA96GSP	
08F4HBC .....	P3NFA96ESP	
08F53AC .....	P3NFA98GSM .....	Uses metal bowl w/ sight gauge
08F53AC1 .....	P3NFA18GSM .....	Uses metal bowl w/ sight gauge
08F53AC9 .....	P3NFA18GSM .....	Uses metal bowl w/ sight gauge
08F53BC .....	P3NFA98ESM .....	Uses metal bowl w/ sight gauge
08F53BC1 .....	P3NFA18ESM .....	Uses metal bowl w/ sight gauge
08F53BC9 .....	P3NFA18ESM .....	Uses metal bowl w/ sight gauge
08F53CC .....	P3NFA98JSM .....	Uses metal bowl w/ sight gauge
08F53CC9 .....	P3NFA18JSM .....	Uses metal bowl w/ sight gauge
08F53XC .....	P3NFA98WSM .....	Uses metal bowl w/ sight gauge
08F53ZC .....	P3NFA98ASM .....	Uses metal bowl w/ sight gauge
08F54AC .....	P3NFA98GSM	
08F54AC1 .....	P3NFA18GSM	
08F54AC9 .....	P3NFA18GSM	
08F54BC .....	P3NFA98ESM	
08F54BC1 .....	P3NFA18ESM	
08F54BC9 .....	P3NFA18ESM	
08F54CC .....	P3NFA98JSM	
08F54CC9 .....	P3NFA18JSM	
08F57AC .....	P3NFA98GSA .....	Uses metal bowl w/ sight gauge
08F57AC1 .....	P3NFA18GSA .....	Uses metal bowl w/ sight gauge
08F57AC9 .....	P3NFA18GSA .....	Uses metal bowl w/ sight gauge
08F57BC .....	P3NFA98ESA .....	Uses metal bowl w/ sight gauge
08F57BC1 .....	P3NFA18ESA .....	Uses metal bowl w/ sight gauge

“08” Model No.	“P3N” Model No.	Notes
08F57BC9	P3NFA18ESA	Uses metal bowl w/ sight gauge
08F57CC	P3NFA98JSA	Uses metal bowl w/ sight gauge
08F57XC	P3NFA98WSA	Uses metal bowl w/ sight gauge
08F57ZC	P3NFA98ASA	Uses metal bowl w/ sight gauge
08F58AC	P3NFA98GSA	
08F58AC1	P3NFA18GSA	
08F58AC9	P3NFA18GSA	
08F58BC	P3NFA98ESA	
08F58BC1	P3NFA18ESA	
08F58BC9	P3NFA18ESA	
08F58CC	P3NFA98JSA	
08F58CC1	P3NFA18JSA	
08F58ZC	P3NFA98ASA	
08F5GAC	P3NFA98GSP	Uses metal bowl w/ sight gauge
08F5HAC	P3NFA98GSP	
08F5HBC	P3NFA98ESP	
08F63AC	P3NFA9PGSM	Uses metal bowl w/ sight gauge, Uses 1-1/2" port (not 1-1/4" port)
08F63AC9	P3NFA1PGSM	Uses metal bowl w/ sight gauge, Uses 1-1/2" port (not 1-1/4" port)
08F63BC	P3NFA9PESM	Uses metal bowl w/ sight gauge, Uses 1-1/2" port (not 1-1/4" port)
08F63CC	P3NFA9PJSM	Uses metal bowl w/ sight gauge, Uses 1-1/2" port (not 1-1/4" port)
08F64AC	P3NFA9PGSM	Uses 1-1/2" port (not 1-1/4" port)
08F64AC9	P3NFA1PGSM	Uses 1-1/2" port (not 1-1/4" port)
08F64BC	P3NFA9PESM	Uses 1-1/2" port (not 1-1/4" port)
08F64BC9	P3NFA1PESM	Uses 1-1/2" port (not 1-1/4" port)
08F64CC	P3NFA9PJSM	Uses 1-1/2" port (not 1-1/4" port)
08F67AC	P3NFA9PGSA	Uses metal bowl w/ sight gauge, Uses 1-1/2" port (not 1-1/4" port)
08F67BC	P3NFA9PESA	Uses metal bowl w/ sight gauge, Uses 1-1/2" port (not 1-1/4" port)
08F67BC1	P3NFA1PESA	Uses metal bowl w/ sight gauge, Uses 1-1/2" port (not 1-1/4" port)
08F67CC	P3NFA9PJSA	Uses metal bowl w/ sight gauge, Uses 1-1/2" port (not 1-1/4" port)
08F67ZC	P3NFA9PASA	Uses metal bowl w/ sight gauge, Uses 1-1/2" port (not 1-1/4" port)
08F68AC	P3NFA9PGSA	Uses 1-1/2" port (not 1-1/4" port)
08F68BC	P3NFA9PESA	Uses 1-1/2" port (not 1-1/4" port)
08F68BC1	P3NFA1PESA	Uses 1-1/2" port (not 1-1/4" port)
08F68CC	P3NFA9PJSA	Uses 1-1/2" port (not 1-1/4" port)
08F6GAC	P3NFA9PGSP	Uses metal bowl w/ sight gauge, Uses 1-1/2" port (not 1-1/4" port)
08F6HAC	P3NFA9PGSP	Uses 1-1/2" port (not 1-1/4" port)
08F6HAC1	P3NFA1PGSP	Uses 1-1/2" port (not 1-1/4" port)
08F6HBC	P3NFA9PESP	Uses 1-1/2" port (not 1-1/4" port)
08F73AC	P3NFA9PGSM	Uses metal bowl w/ sight gauge
08F73AC9	P3NFA1PGSM	Uses metal bowl w/ sight gauge
08F73BC	P3NFA9PESM	Uses metal bowl w/ sight gauge
08F73BC9	P3NFA1PESM	Uses metal bowl w/ sight gauge
08F73CC	P3NFA9PJSM	Uses metal bowl w/ sight gauge
08F73XC	P3NFA9PWSM	Uses metal bowl w/ sight gauge
08F74AC	P3NFA9PGSM	

“08” Model No.	“P3N” Model No.	Notes
08F74AC9	P3NFA1PGSM	
08F74BC	P3NFA9PESM	
08F74BC1	P3NFA1PESM	
08F74BC9	P3NFA1PESM	
08F74CC	P3NFA9PJSM	
08F74ZC	P3NFA9PASM	
08F77AC	P3NFA9PGSA	Uses metal bowl w/ sight gauge
08F77AC1	P3NFA1PGSA	Uses metal bowl w/ sight gauge
08F77AC9	P3NFA1PGSA	Uses metal bowl w/ sight gauge
08F77BC	P3NFA9PESA	Uses metal bowl w/ sight gauge
08F77BC1	P3NFA1PESA	Uses metal bowl w/ sight gauge
08F77CC	P3NFA9PJSA	Uses metal bowl w/ sight gauge
08F77ZC	P3NFA9PASA	Uses metal bowl w/ sight gauge
08F78AC	P3NFA9PGSA	
08F78AC9	P3NFA1PGSA	
08F78BC	P3NFA9PESA	
08F78BC1	P3NFA1PESA	
08F78BC9	P3NFA1PESA	
08F78CC	P3NFA9PJSA	
08F78ZC	P3NFA9PASA	
08F7GAC	P3NFA9PGSP	Uses metal bowl w/ sight gauge
08F7HAC	P3NFA9PGSP	
08F7HBC	P3NFA9PESP	
08L44AC	P3NLA96LSN	Tamper Resistant Knob is Standard
08L44BC	P3NLA96LSN	
08L44BC1	P3NLA16LSN	
08L44BC9	P3NLA16LSN	
08L44BCSB	P3NLA96LSN	
08L44EC	P3NLA96LSH	Tamper Resistant Knob is Standard
08L44FC	P3NLA96LSH	
08L48AC	P3NLA96LSS	Tamper Resistant Knob is Standard
08L48AC9	P3NLA16LSS	Tamper Resistant Knob is Standard
08L48BC	P3NLA96LSS	
08L4MAC	P3NLA96LSA	Tamper Resistant Knob is Standard
08L4MBC	P3NLA96LSA	
08L53BC	P3NLA98LSN	Uses sight gauge
08L54AC	P3NLA98LSN	Tamper Resistant Knob is Standard
08L54AC1	P3NLA18LSN	Tamper Resistant Knob is Standard
08L54AC9	P3NLA18LSN	Tamper Resistant Knob is Standard
08L54BC	P3NLA98LSN	
08L54BC1	P3NLA18LSN	
08L54BC9	P3NLA18LSN	
08L54EC	P3NLA98LSH	Tamper Resistant Knob is Standard
08L54EC1	P3NLA18LSH	Tamper Resistant Knob is Standard
08L54FC	P3NLA98LSH	
08L54FC1	P3NLA18LSH	
08L58AC	P3NLA98LSS	Tamper Resistant Knob is Standard
08L58BC	P3NLA98LSS	
08L58BC1	P3NLA18LSS	
08L5MBC	P3NLA98LSA	
08L64AC	P3NLA9PLSN	Tamper Resistant Knob is Standard, Uses 1-1/2" port

“08” Model No.	“P3N” Model No.	Notes	“08” Model No.	“P3N” Model No.	Notes
08L64BC	P3NLA9PLSN	Uses 1-1/2" port	08R511LB	P3NRA98NNL	Uses non-rising knob (not T-handle)
08L64BC9	P3NLA1PLSN	Uses 1-1/2" port	08R511LB1	P3NRA18NNL	Uses non-rising knob (not T-handle)
08L64BCSB	P3NLA9PLSN	Uses 1-1/2" port	08R513AB	P3NRA98BNN	Uses non-rising knob (not T-handle)
08L64FC	P3NLA9PLSH	Uses 1-1/2" port	08R513AB1	P3NRA18BNN	Uses non-rising knob (not T-handle)
08L68AC	P3NLA9PLSS	Tamper Resistant Knob is Standard, Uses 1-1/2" port	08R513AB9	P3NRA18BNN	Uses non-rising knob (not T-handle)
08L68BC	P3NLA9PLSS	Uses 1-1/2" port	08R513LB	P3NRA98NNN	Uses non-rising knob (not T-handle)
08L6MAC	P3NLA9PLSA	Tamper Resistant Knob is Standard, Uses 1-1/2" port	08R515AB	P3NRA98BNH	Uses non-rising knob (not T-handle)
08L6MBC	P3NLA9PLSA	Uses 1-1/2" port	08R515AB1	P3NRA18BNH	Uses non-rising knob (not T-handle)
08L74AC	P3NLA9PLSN	Tamper Resistant Knob is Standard	08R515AB9	P3NRA18BNH	Uses non-rising knob (not T-handle)
08L74BC	P3NLA9PLSN		08R515LB	P3NRA98NNH	Uses non-rising knob (not T-handle)
08L74BC1	P3NLA1PLSN		08R516AB	P3NRA98BNN	Uses non-rising knob (not T-handle)
08L74BC9	P3NLA1PLSN		08R516AB1	P3NRA18BNN	Uses non-rising knob (not T-handle)
08L74EC	P3NLA9PLSH	Tamper Resistant Knob is Standard	08R516LB	P3NRA98NNM	Uses non-rising knob (not T-handle)
08L74FC	P3NLA9PLSH		08R518AB	P3NRA98BNG	Uses non-rising knob (not T-handle)
08L78BC	P3NLA9PLSS		08R518AB1	P3NRA18BNG	Uses non-rising knob (not T-handle)
08L7MBC	P3NLA9PLSA		08R518AB9	P3NRA18BNG	Uses non-rising knob (not T-handle)
08R411AB	P3NRA96BNL	Uses non-rising knob (not T-handle)	08R518LB	P3NRA98NNG	Uses non-rising knob (not T-handle)
08R411AB1	P3NRA16BNL	Uses non-rising knob (not T-handle)	08R521AB	P3NRA98BNJ	Uses non-rising knob (not T-handle)
08R411LB	P3NRA96NNL	Uses non-rising knob (not T-handle)	08R521AB9	P3NRA18BNJ	Uses non-rising knob (not T-handle)
08R413AB	P3NRA96BNN	Uses non-rising knob (not T-handle)	08R521LB	P3NRA98NNJ	Uses non-rising knob (not T-handle)
08R413AB1	P3NRA16BNN	Uses non-rising knob (not T-handle)	08R611AB	P3NRA9PBNL	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R413AB9	P3NRA16BNN	Uses non-rising knob (not T-handle)	08R611AB9	P3NRA1PBNL	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R413LB	P3NRA96NNN	Uses non-rising knob (not T-handle)	08R611LB	P3NRA9PNNL	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R415AB	P3NRA96BNH	Uses non-rising knob (not T-handle)	08R613AB	P3NRA9PBNN	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R415AB1	P3NRA16BNH	Uses non-rising knob (not T-handle)	08R613AB1	P3NRA1PBNN	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R415LB	P3NRA96NNH	Uses non-rising knob (not T-handle)	08R613AB9	P3NRA1PBNN	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R416AB	P3NRA96BNN	Uses non-rising knob (not T-handle)	08R613LB	P3NRA9PNNN	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R416LB	P3NRA96NNM	Uses non-rising knob (not T-handle)			
08R418AB	P3NRA96BNG	Uses non-rising knob (not T-handle)			
08R418AB1	P3NRA16BNG	Uses non-rising knob (not T-handle)			
08R418LB	P3NRA96NNG	Uses non-rising knob (not T-handle)			
08R421AB	P3NRA96BNJ	Uses non-rising knob (not T-handle)			
08R421LB	P3NRA96NNJ	Uses non-rising knob (not T-handle)			
08R511AB	P3NRA98BNL	Uses non-rising knob (not T-handle)			
08R511AB1	P3NRA18BNL	Uses non-rising knob (not T-handle)			
08R511AB9	P3NRA18BNL	Uses non-rising knob (not T-handle)			

“08” Model No.	“P3N” Model No.	Notes
08R615AB	P3NRA9PBNH	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R615LB	P3NRA9PNNH	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R616AB	P3NRA9PBNM	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R616LB	P3NRA9PNNM	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R618AB	P3NRA9PBNG	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R618AB1	P3NRA1PBNG	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R618LB	P3NRA9PNNG	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R621AB	P3NRA9PBNJ	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R621AB1	P3NRA1PBNJ	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R621LB	P3NRA9PNNJ	Uses 1-1/2" port (not 1-1/4" port), Uses non-rising knob (not T-handle)
08R711AB	P3NRA9PBNL	Uses non-rising knob (not T-handle)
08R711AB9	P3NRA1PBNL	Uses non-rising knob (not T-handle)
08R711LB	P3NRA9PNNL	Uses non-rising knob (not T-handle)
08R713AB	P3NRA9PBNN	Uses non-rising knob (not T-handle)
08R713AB1	P3NRA1PBNN	Uses non-rising knob (not T-handle)
08R713AB9	P3NRA1PBNN	Uses non-rising knob (not T-handle)
08R713LB	P3NRA9PNNN	Uses non-rising knob (not T-handle)
08R715AB	P3NRA9PBNH	Uses non-rising knob (not T-handle)
08R715AB9	P3NRA1PBNH	Uses non-rising knob (not T-handle)
08R715LB	P3NRA9PNNH	Uses non-rising knob (not T-handle)
08R716AB	P3NRA9PBNM	Uses non-rising knob (not T-handle)
08R716AB9	P3NRA1PBNM	Uses non-rising knob (not T-handle)
08R716LB	P3NRA9PNNM	Uses non-rising knob (not T-handle)
08R718AB	P3NRA9PBNG	Uses non-rising knob (not T-handle)
08R718AB1	P3NRA1PBNG	Uses non-rising knob (not T-handle)
08R718AB9	P3NRA1PBNG	Uses non-rising knob (not T-handle)

“08” Model No.	“P3N” Model No.	Notes
08R718LB	P3NRA9PNNG	Uses non-rising knob (not T-handle)
08R721AB	P3NRA9PBNJ	Uses non-rising knob (not T-handle)
08R721AB9	P3NRA1PBNJ	Uses non-rising knob (not T-handle)
08R721LB	P3NRA9PNNJ	Uses non-rising knob (not T-handle)
13F44ED	P3NFA96DSM	
13F44ED1	P3NFA16DSM	
13F44EDN	P3NFA96CSM	
13F44HD	P3NFA96QSM	
13F44HDN	P3NFA969SM	
13F48ED	P3NFA96DSA	
13F48ED1	P3NFA16DSA	
13F48EDN	P3NFA96CSA	
13F48HD	P3NFA96QSA	
13F48HD1	P3NFA16QSA	
13F4HED	P3NFA96DSP	
13F4HHD	P3NFA96QSP	
13F54ED	P3NFA98DSM	
13F54ED1	P3NFA18DSM	
13F54ED9	P3NFA18DSM	
13F54EDN	P3NFA98CSM	
13F54HD	P3NFA98QSM	
13F54HDN	P3NFA989SM	
13F58ED	P3NFA98DSA	
13F58ED1	P3NFA18DSA	
13F58ED9	P3NFA18DSA	
13F58EDN	P3NFA98CSA	
13F58HD	P3NFA98QSA	
13F58HD9	P3NFA18QSA	
13F58HDN	P3NFA989SA	
13F5HED	P3NFA98DSP	
13F5HHD	P3NFA98QSP	
13F64ED	P3NFA9PDSM	Uses 1-1/2" port (not 1-1/4" port)
13F64EDN	P3NFA9PCSM	Uses 1-1/2" port (not 1-1/4" port)
13F64HD	P3NFA9PQSM	Uses 1-1/2" port (not 1-1/4" port)
13F68ED	P3NFA9PDSA	Uses 1-1/2" port (not 1-1/4" port)
13F68ED1	P3NFA1PDSA	Uses 1-1/2" port (not 1-1/4" port)
13F68EDN	P3NFA9PCSA	Uses 1-1/2" port (not 1-1/4" port)
13F68HD	P3NFA9PQSA	Uses 1-1/2" port (not 1-1/4" port)
13F68HDN	P3NFA9P9SA	Uses 1-1/2" port (not 1-1/4" port)
13F6HED	P3NFA9PDSP	Uses 1-1/2" port (not 1-1/4" port)
13F6HEDN	P3NFA9PCSP	Uses 1-1/2" port (not 1-1/4" port)
13F6HHD	P3NFA9PQSP	Uses 1-1/2" port (not 1-1/4" port)
13F74ED	P3NFA9PDSM	
13F74EDN	P3NFA9PCSM	
13F74HD	P3NFA9PQSM	
13F78ED	P3NFA9PDSA	
13F78ED1	P3NFA1PDSA	
13F78ED9	P3NFA1PDSA	
13F78HD	P3NFA9PQSA	

“08” Model No.	“P3N” Model No.	Notes
13F78HDN	P3NFA9P9SA	
13F7HED	P3NFA9PDSP	
13F7HHD	P3NFA9PQSP	
13R414PB	P3NRA96NPP	
13R415PB	P3NRA96BPP	
13R415PB9	P3NRA16BPP	
13R421PB	P3NRA96BPJ	
13R421PB1	P3NRA16BPJ	
13R514PB	P3NRA98NPP	
13R515PB	P3NRA98BPP	
13R515PB1	P3NRA18BPP	
13R515PB9	P3NRA18BPP	
13R519PB	P3NRA98NPJ	
13R521PB	P3NRA98BPJ	
13R521PB1	P3NRA18BPJ	
13R614PB	P3NRA9PNPP	Uses 1-1/2" port (not 1-1/4" port)
13R615PB	P3NRA9BPPP	Uses 1-1/2" port (not 1-1/4" port)
13R615PB9	P3NRA1PBPP	Uses 1-1/2" port (not 1-1/4" port)
13R621PB	P3NRA9BPBJ	Uses 1-1/2" port (not 1-1/4" port)
13R621PB1	P3NRA1PBPJ	Uses 1-1/2" port (not 1-1/4" port)
13R714PB	P3NRA9PNPP	
13R715PB	P3NRA9BPPP	
13R715PB9	P3NRA1PBPP	
13R719PB	P3NRA9PNPJ	
13R721PB	P3NRA9BPBJ	
13R721PB1	P3NRA1PBPJ	
18A43A13A4AC	P3NCB96SGMNNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
18A43A13A4BC	P3NCB96SGMNNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A43A13A8AC	P3NCB96SGMNNLSA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
18A43A13A8BC	P3NCB96SGMNNLSA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A43A13L4FC	P3NCB96SGMMNLHA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A43A16A4AC	P3NCB96SGMNNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
18A43A18A4BC	P3NCB96SGMNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A43A18A4EC	P3NCB96SGMNLHA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
18A43A21A4BC	P3NCB96SGMNJLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A43B18A4FC	P3NCB96SEMNLHA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A44A13A4BC	P3NCB96SGMNNLNA	Changed from Micro-Mist to Mist
18A44A18A4BC	P3NCB96SGMNLNA	Changed from Micro-Mist to Mist
18A44A21A4BC	P3NCB96SGMNJLNA	Changed from Micro-Mist to Mist
18A44B13A4BC	P3NCB96SEMNNLNA	Changed from Micro-Mist to Mist
18A47A13A4BC	P3NCB96SGANNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge

“08” Model No.	“P3N” Model No.	Notes
18A47A13A8BC	P3NCB96SGANNLSA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A47A15A4BC	P3NCB96SGANHLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A47A18A4BC	P3NCB96SGANGLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A47A21A4BC	P3NCB96SGANJLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A47B13A4BC	P3NCB96SEANNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A48A13A4BC	P3NCB96SGANNLNA	Changed from Micro-Mist to Mist
18A48A13A4FC	P3NCB96SGANNLHA	Changed from Micro-Mist to Mist
18A48A13A8BC	P3NCB96SGANNLSA	Changed from Micro-Mist to Mist
18A48A18A4AC	P3NCB96SGANGLNA	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A48A18A4BC	P3NCB96SGANGLNA	Changed from Micro-Mist to Mist
18A48A18A4FC	P3NCB96SGANGLHA	Changed from Micro-Mist to Mist
18A48A18A8BC	P3NCB96SGANGLSA	Changed from Micro-Mist to Mist
18A48B13A4AC	P3NCB96SEANNLNA	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A48B13A4BC	P3NCB96SEANNLNA	Changed from Micro-Mist to Mist
18A48B18A4AC	P3NCB96SEANGLNA	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A4GB13A4AC	P3NCB96SEPNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
18A53A13A4BC	P3NCB98SGMNNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A53A15A8BC	P3NCB98SGMNLHA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A53A18A4AC	P3NCB98SGMNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
18A53A18A4BC	P3NCB98SGMNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A53A18L4BC	P3NCB98SGMMGLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A53A21A4BC	P3NCB98SGMNJLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A53A21A8BC	P3NCB98SGMNJLSA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A53B13A4BC	P3NCB98SEMNNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A53B18A4BC	P3NCB98SEMNLNA	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A54A13A4AC	P3NCB98SGMNNLNA	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A54A13A4BC	P3NCB98SGMNNLNA	Changed from Micro-Mist to Mist
18A54A13A4BC1	P3NCB18SGMNNLNA	Changed from Micro-Mist to Mist
18A54A18A4AC	P3NCB98SGMNLNA	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A54A18A4BC	P3NCB98SGMNLNA	Changed from Micro-Mist to Mist
18A54A18A8BC	P3NCB98SGMNLNA	Changed from Micro-Mist to Mist
18A54A18AMB	P3NCB98SGMNLAA	Changed from Micro-Mist to Mist
18A54B13A4BC	P3NCB98SEMNNLNA	Changed from Micro-Mist to Mist
18A54B18A4AC	P3NCB98SEMNLNA	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A54B18A4BC	P3NCB98SEMNLNA	Changed from Micro-Mist to Mist

“08” Model No.	“P3N” Model No.	Notes
18A54B18A4BC1	P3NCB18SEMNLNA	... Changed from Micro-Mist to Mist
18A57A11A4BC	P3NCB98SGANLLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A57A13A4AC	P3NCB98SGANLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
18A57A13A4BC	P3NCB98SGANLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A57A13A4FC	P3NCB98SGANLHA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A57A13A8BC	P3NCB98SGANLSA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A57A15A4BC	P3NCB98SGANHLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A57A18A4BC	P3NCB98SGANGLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A57A18A8BC	P3NCB98SGANGLSA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A57A21A4AC	P3NCB98SGANJLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
18A57B13A4BC	P3NCB98SEANLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A57B18A4BC	P3NCB98SEANGLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A58A13A4BC	P3NCB98SGANLNA	... Changed from Micro-Mist to Mist
18A58A13AMBC	P3NCB98SGANLAA	... Changed from Micro-Mist to Mist
18A58A18A4BC	P3NCB98SGANGLNA	... Changed from Micro-Mist to Mist
18A58B13A4BC	P3NCB98SEANLNA	... Changed from Micro-Mist to Mist
18A58B18A4AC	P3NCB98SEANGLNA	... Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A58B18A4BC	P3NCB98SEANGLNA	... Changed from Micro-Mist to Mist
18A5GA13A4BC	P3NCB98SGPNNLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A5HB18A4BC	P3NCB98SEPNGLNA	... Changed from Micro-Mist to Mist
18A5HB18A8BC	P3NCB98SEPNGLSA	... Changed from Micro-Mist to Mist
18A63A13A4BC	P3NCB9PSGMNLLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Uses 1-1/2" port
18A63A18A4BC	P3NCB9PSGMNGLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Uses 1-1/2" port
18A63B13A4FC	P3NCB9PSEMNNLHA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Uses 1-1/2" port
18A64A13A4BC	P3NCB9PSGMNLLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A64A13A4EC	P3NCB9PSGMNLLHA	... Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard, Uses 1-1/2" port
18A64A13A4FC	P3NCB9PSGMNLLHA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A64A18A4BC	P3NCB9PSGMNGLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A64A18AMBC	P3NCB9PSGMNGLAA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A64B13A4BC	P3NCB9PSEMNNLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A64B18A4BC1	P3NCB1PSEMNLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port

“08” Model No.	“P3N” Model No.	Notes
18A67A13A4AC	P3NCB9PSGANLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard, Uses 1-1/2" port
18A67A13A4EC	P3NCB9PSGANLHA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard, Uses 1-1/2" port
18A67A18A4AC	P3NCB9PSGANGLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard, Uses 1-1/2" port
18A67A18A4BC	P3NCB9PSGANGLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Uses 1-1/2" port
18A67A18A8BC	P3NCB9PSGANGLSA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Uses 1-1/2" port
18A67B21A4FC	P3NCB9PSEANJLHA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Uses 1-1/2" port
18A68A13A4BC	P3NCB9PSGANLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A68A15A4BC	P3NCB9PSGANHLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A68A16A4BC	P3NCB9PSGANMLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A68A18A4BC	P3NCB9PSGANGLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A68B13A4BC	P3NCB9PSEANLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A68B18A4AC	P3NCB9PSEANGLNA	... Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard, Uses 1-1/2" port
18A68B18A4BC	P3NCB9PSEANGLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A6HA18A4BC	P3NCB9PSGPNGLNA	... Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A73A13A4BC	P3NCB9PSGMNLLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A73A18A4BC	P3NCB9PSGMNGLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A73A21A4BC	P3NCB9PSGMNLLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A73B13A4BC	P3NCB9PSEMNNLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A74A13A4EC	P3NCB9PSGMNLLHA	... Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A74A16A4AC	P3NCB9PSGMNLLNA	... Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A74A18A4AC	P3NCB9PSGMNGLNA	... Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A74A18A4BC	P3NCB9PSGMNGLNA	... Changed from Micro-Mist to Mist
18A74A18A4BC9	P3NCB1PSGMNGLNA	... Changed from Micro-Mist to Mist
18A74B18A4BC	P3NCB9PSEMNLNA	... Changed from Micro-Mist to Mist
18A77A13A4BC	P3NCB9PSGANLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge
18A77A13A4EC	P3NCB9PSGANLHA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge, Tamper Resistant Knob is Standard
18A77A18A4BC	P3NCB9PSGANGLNA	... Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge

“08” Model No.	“P3N” Model No.	Notes	“08” Model No.	“P3N” Model No.	Notes
18A77B18A4BC ...	P3NCB9PSEANGLNA ....	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge	18L54FC .....	P3NLA98LSH .....	Changed from Micro-Mist to Mist
18A78A13A4BC ...	P3NCB9PSGANLNA ...	Changed from Micro-Mist to Mist	18L54FC1 .....	P3NLA18LSH .....	Changed from Micro-Mist to Mist
18A78A18A4AC ...	P3NCB9PSGANGLNA ...	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard	18L54FC9 .....	P3NLA18LSH .....	Changed from Micro-Mist to Mist
18A78A18A4BC ...	P3NCB9PSGANGLNA ...	Changed from Micro-Mist to Mist	18L58AC .....	P3NLA98LSS .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18A78B13A4BC ...	P3NCB9PSEANLNA ....	Changed from Micro-Mist to Mist	18L58BC .....	P3NLA98LSS .....	Changed from Micro-Mist to Mist
18A78B18A4AC ...	P3NCB9PSEANGLNA ....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard	18L5MBC .....	P3NLA98LSA .....	Changed from Micro-Mist to Mist
18A78B21AMAC ..	P3NCB9PSEANJLAA .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard	18L64AC .....	P3NLA9PLSN .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard, Uses 1-1/2" port
18A78B21L8BC ...	P3NCB9PSEAMJLSA ....	Changed from Micro-Mist to Mist	18L64BC .....	P3NLA9PLSN .....	Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A7GA18A4BC ..	P3NCB9PSGPNGLNA ...	Changed from Micro-Mist to Mist, Uses metal bowl w/ sight gauge	18L64BC1 .....	P3NLA1PLSN .....	Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A7HA18A4FC ...	P3NCB9PSGPNGLHA ...	Changed from Micro-Mist to Mist	18L64BC9.....	P3NLA1PLSN .....	Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A7HA18A8BC ..	P3NCB9PSGPNGLSA ....	Changed from Micro-Mist to Mist	18L64FC .....	P3NLA9PLSH .....	Changed from Micro-Mist to Mist, Uses 1-1/2" port
18A7HA21A4BC ..	P3NCB9PSGPNJLNA ....	Changed from Micro-Mist to Mist	18L68AC .....	P3NLA9PLSS .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard, Uses 1-1/2" port
18L44AC .....	P3NLA96LSN .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard	18L68BC .....	P3NLA9PLSS .....	Changed from Micro-Mist to Mist, Uses 1-1/2" port
18L44BC .....	P3NLA96LSN .....	Changed from Micro-Mist to Mist	18L6MBC .....	P3NLA9PLSA .....	Changed from Micro-Mist to Mist, Uses 1-1/2" port
18L44BC9 .....	P3NLA16LSN .....	Changed from Micro-Mist to Mist	18L74AC .....	P3NLA9PLSN .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18L44EC .....	P3NLA96LSH .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard	18L74BC .....	P3NLA9PLSN .....	Changed from Micro-Mist to Mist
18L44FC .....	P3NLA96LSH .....	Changed from Micro-Mist to Mist	18L74BC9.....	P3NLA1PLSN .....	Changed from Micro-Mist to Mist
18L48AC .....	P3NLA96LSS .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard	18L74EC .....	P3NLA9PLSH .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18L48BC .....	P3NLA96LSS .....	Changed from Micro-Mist to Mist	18L74FC .....	P3NLA9PLSH .....	Changed from Micro-Mist to Mist
18L4MAC .....	P3NLA96LSA .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard	18L74FC9 .....	P3NLA1PLSH .....	Changed from Micro-Mist to Mist
18L4MBC .....	P3NLA96LSA .....	Changed from Micro-Mist to Mist	18L78AC .....	P3NLA9PLSS .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard
18L54AC .....	P3NLA98LSN .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard	18L78BC .....	P3NLA9PLSS .....	Changed from Micro-Mist to Mist
18L54AC1 .....	P3NLA18LSN .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard	18L7MBC .....	P3NLA9PLSA .....	Changed from Micro-Mist to Mist
18L54BC .....	P3NLA98LSN .....	Changed from Micro-Mist to Mist			
18L54BC1 .....	P3NLA18LSN .....	Changed from Micro-Mist to Mist			
18L54BC9 .....	P3NLA18LSN .....	Changed from Micro-Mist to Mist			
18L54EC .....	P3NLA98LSH .....	Changed from Micro-Mist to Mist, Tamper Resistant Knob is Standard			



**Parker Hannifin Corporation**  
 Pneumatic Division North America  
 8676 E. M89  
 P.O. Box 901  
 Richland, MI 49083 USA  
 Tel: (616) 629-5000  
 Fax: (616) 629-5385

Customer/Technical Service

Tel: (616) 629-5575  
 Fax: (800) 648-5480  
 Fax: (800) 426-3259  
 Web site: [www.parker.com/pneumatic](http://www.parker.com/pneumatic)  
 E-mail: [PDNMKTG@parker.com](mailto:PDNMKTG@parker.com)